

## CustomFit Panel: Installation Instructions

1. Prepare surface material with appropriate substrates per details and installation notes.
2. Mark level lines onto scratch coat @ 8-12" o.c. to maintain level.
3. Start installation at corner of structure if applicable. The corners should stack tight as to not create a seam. Seams should not be viable and vertical seams must stagger from seams above and below. Contractor to apply 'type S' mortar to the entire back of each panel. Panels should be firmly applied to the wall with a slight wiggle to remove any air that may be trapped. Remove any excess mortar displaced at sides, top and bottom of installed panel prior to placing next panel.

### Installation Tips:

1. Panels must be cut if size adjustments are needed. Do not break panels.
2. When reaching a stopping point measure the distance to the wall and saw the panel pieces flush.
3. Make sure the edges of pieces are clean to achieve a tight stack.

### Cleaning Instructions

1. After installation, panels should be rinsed with a low pressure hose (never use high pressure)
2. The CustomFit Panels may be cleaned after installation with a mild detergent and a medium bristle brush.